

## V-Tech Connect To Cell – Compatibility List – 11/2011

Acer Acer beTouch E210  
Acer acer E400  
Acer acer P400  
Acer DX650  
Acer E200  
Acer Liquid E  
Acer Liquid Mini (E310)  
Acer M900  
Acer S110  
Acer Smart handheld  
Acer Smart handheld  
Acer Smart handheld E100  
Acer Smart handheld E101  
Alcatel MISS SIXTY MSX10  
Alcatel OT-800/ OT-800A  
Alcatel OT-802/ OT-802A  
Alcatel OT-806/ OT-806A/ OT-806D/ OT-807/ OT-807A/ OT-807D  
Alcatel OT-808/ OT-808A  
Alcatel OT-880/ OT-880A  
Alcatel OT-980/ OT-980A  
Apple iPhone 2G  
Apple iPhone 3G  
Apple iPhone 3Gs  
Apple iPhone 4  
AS670  
BL20N  
Casio Hitachi C721  
Chi Mei AQ4  
Chi Mei P300  
CM200 / BM200/ LW200/ MN200 / CX200B / CX200 / JN200)  
FIH FM600  
FIH N700  
FIH PDA Phone  
FIH test\_RM-383  
FIH ViewPad7  
Fujitsu T-01C  
Garmin asus G60  
Global High Tech GHT Maestro  
Google Google Nexus S  
Hewlett-Packard HSTNH-P21C  
HP iPad912  
HTC Dash 3G  
HTC Droid Eris  
HTC FUZE (TM ) P4600  
HTC G1  
HTC HD2  
HTC Hero  
HTC HTC HD mini  
HTC HTC Tattoo  
HTC HTC Touch Diamond 2 T5353  
HTC HTC Wildfire A3333  
HTC MyTouch 3g  
HTC Nexus One  
HTC Pure  
HTC SHADOW  
HTC Shadow 2009  
HTC SMT 5800  
HTC Snap

HTC Tilt 2  
HTC Touch Diamond  
HTC Touch Dual  
HTC Touch HD  
HTC Touch Pro  
HTC Touch Pro 2  
HTC Evo 4G  
HTC HD7  
HTC Incredible  
HTC Ozone  
HTC Surround  
HTC Touch Pro2  
HTC ADR6200VW  
HTC ADR6300  
HTC ADR6300  
HTC CDMA\_HTI11  
HTC CEDA100 Series  
HTC CEDA100 Series  
HTC CEDA100 Series (WM6.5)  
HTC EVO  
HTC HERO200  
HTC HTC Hero  
HTC HTC Snap  
HTC HTC Touch Diamond2  
HTC HTC Touch2  
HTC HTC Wildfire  
HTC Nexus One  
HTC PB00 Series  
HTC PB65 series  
HTC PB76100  
HTC PB81 Series  
HTC PB92100  
HTC PB92110  
HTC PB92110 series  
HTC PB99 (CDMA)  
HTC PB99 Android 2.2 series  
HTC PB99400  
HTC PC10100  
HTC PC10xxx  
HTC PC36100  
HTC PC36100  
HTC PC40100  
HTC PC402XX  
HTC PC57 Series  
HTC PC63xxx Android 2.2  
HTC PC70 series  
HTC PC92xxx  
HTC PC96 Series  
HTC PC991XX  
HTC PD051XX  
HTC PD06100  
HTC PD11 Series  
HTC PD15xxx  
HTC PD2610000  
HTC PD29xxx  
HTC PD42XXX  
HTC PD67100  
HTC PD98xxx(A9192)  
HTC PG05XXX

HTC PG06XXX  
HTC PG321XX  
HTC PG32XXX  
HTC RHOD100 Series  
HTC RHOD50000 Series  
HTC TWIN10000 Series  
HTC WHIT10000 Series  
HUAWEI C8150  
HUAWEI C8150-1  
HUAWEI HUAWEI C8500  
HUAWEI HUAWEI C8600/ HUAWEI M860  
HUAWEI HUAWEI U8300/ U8300  
HUAWEI S31HW/ U8150-92/ HUAWEI U8150-92  
HUAWEI U8150-A  
HUAWEI U8150-D  
HUAWEI UM840  
Inventec T-101  
iWOW Libero  
KT Tech EV-S100  
KT Tech KM-S120  
Kyocera CLIP  
Kyocera Glide-M1400  
Kyocera K50  
Kyocera M2000  
Kyocera Mobile Phone 16 (E76)  
Kyocera S1310  
Kyocera S2300  
Kyocera S2410  
Kyocera SANYO SCP-3810  
Kyocera SCP-2700  
Kyocera SCP-8600  
Kyocera Torino  
LG BL20v  
LG BL40  
LG CF360  
LG Chocolate Touch  
LG Dare VX9700  
LG enV3  
LG eXpo (GW820)  
LG GB250  
LG GC900  
LG GD 580 Lollipop  
LG GD310 Ice Cream 2  
LG GD510 Pop  
LG GD900  
LG Glance  
LG GM750  
LG GT505  
LG GT540  
LG GU230  
LG GU285  
LG GW520  
LG GW620  
LG GX200  
LG GX500  
LG INCITE  
LG KC910  
LG KM555  
LG KM900

LG KP275  
LG KP500  
LG KS360  
LG Lotus LX600  
LG LX290  
LG LX370  
LG Neon (TM ) GT365  
LG Rumor 2  
LG Scoop / AX-260  
LG Shine 2  
LG Shine II GD710 AT&T  
LG Shine KE970  
LG Versa  
LG Voyager VX10000  
LG VX5500  
LG VX8360  
LG VX8610  
LG Xenon (TM ) GR500  
LG LX400  
LG enV3 VX9200  
LG Vortex  
LG BL20df/ BL20cf  
LG BL40/ BL40g/ BL40f  
LG BL40e  
LG BL42/ BL42e/ BL42v/ BL42k/ BL42N/ BL20/ BL20e/ BL20v/ BL20k/  
LG GC900/ GC900F  
LG GC900e  
LG GC970/ GC970h  
LG GD510  
LG GD510N  
LG GD550  
LG GD550e  
LG GD570  
LG GD570AW, GD570AV  
LG GD880/ GC970  
LG GD880f, GD880g  
LG GD900/ GD900e  
LG GM210  
LG GM360i  
LG GM600  
LG GM730/ GM730f/ GM735/ GM730e  
LG GM750  
LG GM750h  
LG GM750Q  
LG GR700  
LG GS290  
LG GS390  
LG GS500  
LG GS500f for PCL  
LG GS500f, GS500g, GS500k, GS500v  
LG GS500gX  
LG GS505  
LG GT350  
LG GT350F  
LG GT350i  
LG GT360  
LG GT370  
LG GT400/ GT405  
LG GT500/ GT505

LG GT550  
LG GT620  
LG GT950Q  
LG GU280, GU285, GU285f, GU285g  
LG GU280f  
LG GU282  
LG GU290/ GU290f  
LG GU290v  
LG GU295/ GU292  
LG GU295f, GU295g  
LG GU295g  
LG GU297 , GU297a  
LG GW300, LG900G  
LG GW300FD, GW305  
LG GW380/ GW370B/ GW375/ GW382f/ GW380f/ GW380g  
LG GW525gX  
LG GW550  
LG GW550h  
LG GW820, GW825, GW825v  
LG GX500  
LG KC910, KC910Q, KC910Qa, KC910e, KC910i  
LG KM553  
LG KM555  
LG KM555e  
LG KM555R  
LG KM570  
LG KP500N  
LG KP501/ KP502/ KP550  
LG KP505  
LG KS365  
LG KT770, KT770f  
LG L-04C  
LG LG 3G Mobile Phone (GD910)  
LG LG 3G Mobile Phone (GT950)  
LG LG 3G Mobile Phone (LG- GT540/ GT540f/ GT540g)  
LG LG 3G Mobile phone (LG-C550 / LG-C550f)  
LG LG 3G Mobile Phone (LG-GB258)  
LG LG 3G Mobile Phone (LG-P350)  
LG LG 3G Mobile Phone(GM730E)  
LG LG 3G Mobile Phone(GW820)  
LG LG 3G Mobile Phone(KB770, KB775, KB775f)  
LG LG 3G Mobile Phone(LG-KU3800)  
LG LG 3G Mobile Phone(LG-T320, LG-T320e, LG-T320g, LG-T320v,  
LG LG CDMA Mobile Phone (LG-CX7100)  
LG LG CDMA Mobile Phone (LG-LG5500X for Koodo)  
LG LG CDMA Mobile Phone (LG-MN180)  
LG LG CDMA Mobile Phone (LG-UN200/ LG501C/ AN200/ VM200 /  
LG LG CDMA Mobile Phone (LG-VS910)  
LG LG CDMA Mobile Phone (VX7100)  
LG LG CDMA Mobile Phone (VX8575/ AX8575)  
LG LG CDMA Mobile Phone(LG LN510)  
LG LG CDMA Mobile Phone(LG- LN510)  
LG LG CDMA Mobile Phone(LG220C)  
LG LG CDMA Mobile Phone(LG-CX9200)  
LG LG CDMA Mobile Phone(LG-CX9600)  
LG LG CDMA mobile phone(LG-UX700, LG-AX700, MT700, LW700,  
LG LG GSM Mobile Phone (LG-C320i)  
LG LG GSM/ GPRS/ EDGE Mobile Phone (GM360)  
LG LG KM900, LG KM900e, LG KM900f, LG KM900g

LG LG- LG265X  
LG LG TD-SCDMA Mobile Phone (GT910s)  
LG LG TD-SCDMA Mobile Phone(LG KT878)  
LG LG WCDMA Mobile Phone (LG-SU550)  
LG LG WCDMA Mobile Phone (LG-SU920, LG-KU9200)  
LG LG WCDMA Mobile Phone(LG-SU130)  
LG LG WCDMA Mobile Phone(LG-SU630)  
LG LG WCDMA Mobile Phone(LG-SU900/ LG-KU9000/ LG-LU9000)  
LG LG230(CX230), LG231(CX231), LG231C(CX231C)  
LG LG370  
LG LG700V, CX700V  
LG LG-A310/ LG-A310f/ LG-A310k/ LG-A315/ LG-A315v  
LG LG-AX265  
LG LG-AX265 [Not Approved by SIG]  
LG LG-AX8370  
LG LG-AX840  
LG LG-C320  
LG LG-C510/ C510  
LG LG-C570f  
LG LG-C570g  
LG LG-C710h/ LG-C710  
LG LG-C900  
LG LG-C900N, LG-C900k, LG-C900B  
LG LG-CX5500X  
LG LG-E500  
LG LG-E720, LG-E720b, LG-E720k  
LG LG-E900, LG-E900h  
LG LG-GB250  
LG LG-GD970  
LG LG-GM310/ LG-GM310f/ LG-GM310g  
LG LG-GW370  
LG LG-GW520/ LG-GW525/ GW525f/ GW525g  
LG LG-GW610  
LG LG-GW820, LG-GW825  
LG LG-JN240  
LG LG-JS750, LG-JS750g  
LG LG-KH3400  
LG LG-KH3400  
LG LG-KH3900  
LG LG-KH8000  
LG LG-KS720  
LG LG-KU2100, LG-SU210, LG-LU2100  
LG LG-KU2200  
LG LG-KU9300  
LG LG-KV700 (Lollipop2)  
LG LG-KV700T  
LG LG-KW730  
LG LG-LB4400  
LG LG-LG265T  
LG LG-LG8575/ LG-MX8575  
LG LG-LU2700  
LG LG-LU3000  
LG LG-LU4500  
LG LG-LU9400  
LG LG-LU9400W  
LG LG-LX295/ LG-LX290  
LG LG-MT375  
LG LG-P500/ LG-P509/ LG-P509TN  
LG LG-P500h

LG LG-P501  
 LG LG-P503  
 LG LG-P505  
 LG LG-P506  
 LG LG-P920/ LG-P925/ LG-P929  
 LG LG-P970  
 LG LG-P990  
 LG LG-SB210  
 LG LG-SB260  
 LG LG-SU310, LG-LU3100  
 LG LG-SU370/ LG-KU3700/ LG-LU3700  
 LG LG-SU410  
 LG LG-SU420/ LG-KU4200  
 LG LG-SU430/ LG-KU4300/ LG-LU4300  
 LG LG-SU660  
 LG LG-SU910/ LG-KU9100/ LG-LU9100  
 LG LG-SU950/ KU9500  
 LG LG-SU960, LG-KU9600  
 LG LG-SV400  
 LG LG-SV770  
 LG LG-T325 , LG-T325f, LG-T325g  
 LG LG-UN430  
 LG LG-US760  
 LG LG-UX310, AX310, MT310(MetroPCS), LP310,  
 LG LGVN270/ LN270/ UN270/ LG270/ LG270C/ LW270/ CX270/  
 LG LG-VN530  
 LG LG-VS660/ LS670/ US670/ LG670C/ MS690/ LW690/ VM670/  
 LG LG-VS740/ US740/ MS740/ AS740  
 LG LG-VS750  
 LG LG-VS760  
 LG LG-VS761  
 LG LG-VX11000  
 LG LG-VX8576  
 LG LG-VX9200  
 LG LN240/ MN240/ LW240/ UN240/ AN240/ VN240/ CX240  
 LG LU2300  
 LG LW375  
 LG LX610/ UX610/ CX610/ LG610/ VM610/ AX610/ UN610/ CN610/  
 LG MT375  
 LG New LG 3G Mobile Phone(GD710)  
 LG New LG CDMA Mobile Phone(LG-LG290C)  
 LG UX220  
 LG UX370  
 LG VER-01  
 LG VN250  
 LG VX5600  
 LG VX8370  
 LG-T320k, LG-T320gv)  
 LG700, CX700, MV700, MX700, MD700, VM700)  
 LW310(LeapWireless(Cricket)), G310, CX310, MV310, MX310,  
 MD310  
 MediaTek MediaTek BlueZ (2.1+EDR)  
 MediaTek Mediatek WM6.5 (EDR2.0)  
 MN270/ TN270/ AN270/ VM270  
 Moto Backflip ME600  
 Moto EM35  
 Moto Z9N  
 Motorola Cliq  
 Motorola Clutch (i465)

Motorola Droid  
Motorola E1  
Motorola E1070  
Motorola E398  
Motorola E8  
Motorola EM30  
Motorola i365  
Motorola i576  
Motorola i776  
Motorola I9  
Motorola K3  
Motorola Karma QA1  
Motorola MOTO (TM ) Z9  
Motorola Q11  
Motorola Q9H  
Motorola RAZR V3  
Motorola RAZR V3xx Pink  
Motorola RAZR2 V9  
Motorola Rival  
Motorola SLVR L72  
Motorola U9  
Motorola V1100  
Motorola V360  
Motorola V365  
Motorola V3i  
Motorola V3x  
Motorola V500  
Motorola V550  
Motorola V551  
Motorola V6  
Motorola V750  
Motorola V80  
Motorola V860  
Motorola V9  
Motorola V950  
Motorola V9x  
Motorola VE20  
Motorola VE66  
Motorola VU30  
Motorola W510  
Motorola W755  
Motorola W766  
Motorola XT701 Milestone  
Motorola Z3  
Motorola Z6w  
Motorola ZN300  
Motorola ZN4  
Motorola ZN5  
Motorola Backflip MB300  
Motorola Cliq MB200  
Motorola Droid 2  
Motorola Droid Pro  
Motorola Droid X  
Motorola A3300c  
Motorola A853  
Motorola A855  
Motorola A955  
Motorola Amphora-i897  
Motorola Athens-i9 R2

Motorola Banfi-i856  
Motorola Bei Hai TD  
Motorola Blackstone-R2  
Motorola Brightwater  
Motorola Castle  
Motorola Cordova  
Motorola Creekside-i886  
Motorola CRUSH  
Motorola EWP3100  
Motorola Fairbanks  
Motorola Finch  
Motorola FR6070, FR6076  
Motorola FR6874  
Motorola Halo  
Motorola Heartland  
Motorola i296-Gallo  
Motorola i410(Nevadacity)  
Motorola i686-Brightwater-2  
Motorola i786w (Mantra)  
Motorola MB200 refresh  
Motorola MB300 Backflip refresh  
Motorola MB501 refresh  
Motorola MB502  
Motorola MB508  
Motorola MB511  
Motorola MB520  
Motorola MB525  
Motorola MB810  
Motorola ME811  
Motorola Milestone XT720  
Motorola Moto A3000  
Motorola Motosurf A3000  
Motorola Motosurf A3100  
Motorola MT716  
Motorola Muscardini  
Motorola Oaknoll  
Motorola Quailhurst iDEN-i786  
Motorola RIVAL (TELUS)  
Motorola Rush  
Motorola VE440  
Motorola VoWLAN Single Mode Smartphone  
Motorola W418G  
Motorola W766  
Motorola WX345  
Motorola WX404  
Motorola XT502  
Motorola XT610  
Motorola XT701  
Motorola XT702  
Motorola XT711  
Motorola XT720  
Motorola XT800  
Motorola XT800+  
Motorola XT800c  
Motorola XT800W  
Motorola XT806  
NEC CASIO KMP7N4Y1-2A  
Nokia 2605  
Nokia 2705

Nokia 2730  
Nokia 2760  
Nokia 3555  
Nokia 3711  
Nokia 5220  
Nokia 5230  
Nokia 5310  
Nokia 5320  
Nokia 5530  
Nokia 5610  
Nokia 5800  
Nokia 6085  
Nokia 6086  
Nokia 6103  
Nokia 6133  
Nokia 6205  
Nokia 6263  
Nokia 6301  
Nokia 6350  
Nokia 6555  
Nokia 6600  
Nokia 6650  
Nokia 6700  
Nokia 6730  
Nokia 7205  
Nokia 7310  
Nokia 7510  
Nokia 7705  
Nokia 8800  
Nokia 2600C  
Nokia 2680s  
Nokia 2720 Fold  
Nokia 2730 Classic  
Nokia 3710 fold  
Nokia 5130 XpressMusic  
Nokia 5330TV  
Nokia 5630Xpress  
Nokia 6220c  
Nokia 6303C  
Nokia 6500 Slide  
Nokia 6600i Slide  
Nokia 6700 Clasic  
Nokia 6700 slide  
Nokia 7100 Supernova  
Nokia 7210 Supernova  
Nokia 7610s  
Nokia C5-00  
Nokia E52  
Nokia E63  
Nokia E66  
Nokia E71  
Nokia E71x  
Nokia E75  
Nokia E90  
Nokia Mural (6750)  
Nokia N73  
Nokia N78  
Nokia N79  
Nokia N85

Nokia N86  
Nokia N96  
Nokia N97  
Nokia N97 Mini  
Nokia Surge (TM ) 6790  
Nokia X3  
Nokia X6  
Nokia Z730C  
Nokia 5230 Nuron  
Nokia N8  
Nokia X6  
Nokia 2705  
Nokia 6788  
Nokia 7705  
Nokia 2332c  
Nokia 6788i  
Nokia C1-03  
Nokia C5-01  
Nokia Nokia 1006  
Nokia Nokia 2705  
Nokia Nokia 3208c  
Nokia Nokia 3720c-2  
Nokia Nokia 5132  
Nokia Nokia 5611  
Nokia Nokia 5730s-1  
Nokia Nokia 6303c  
Nokia Nokia 6316s, 6316s-1  
Nokia Nokia 6350-1b  
Nokia Nokia 6350-1d  
Nokia Nokia 6600i-1c  
Nokia Nokia 6700c  
Nokia Nokia 6700c-1  
Nokia Nokia 6750-1b  
Nokia Nokia 6750-1c  
Nokia Nokia 6760s-1  
Nokia Nokia 6790s-1b  
Nokia Nokia 6790s-1c  
Nokia Nokia 7205  
Nokia Nokia 7208  
Nokia Nokia 7208  
Nokia Nokia 7505 CDMA Mobile Phone  
Nokia Nokia 7705  
Nokia Nokia 8208  
Nokia Nokia E71x  
Nokia Nokia E75-1  
Nokia Nokia E75-2  
Nokia Vertu ASCENT X  
Nokia Vertu Constellation F  
Nokia Vertu Signature SC  
Nokia X3-01  
Nokia X5-00  
Palm Centro  
Palm Pixi  
Palm Pre  
Palm Treo 680  
Palm Treo 800w  
Palm Treo Pro  
Palm Pixi Plus CDMA  
Palm Pre Plus CDMA

Palm P100EWW  
Palm P100UNA/ P100UEU  
Palm P101EWW  
Palm P101UNA, P101UEU  
Palm P120EWW  
Palm P121EWW  
Palm P121UNA, P121UEU  
Palm Treo Pro, T850EWW  
Pantech Matrix Pro (TM )  
Pantech CDM8999\*\*  
Pantech CDMA PTI06 (IS06)  
Pantech IM-A600S  
Pantech IM-A630K (SP33K)  
Pantech IM-A630K (SP33K)  
Pantech IM-A650S  
Pantech IM-A690L  
Pantech IM-A690S  
Pantech IM-A710K  
Pantech MD Cube  
Pantech P2000  
Pantech P2020  
Pantech P6010  
Pantech P7000  
Pantech P7040  
Pantech P8000  
Pantech P9020  
Pantech P9050  
Pantech PIVOT \*\*  
Pantech PIVOT/ TXT8030##  
Pantech Show(TXT8040, VZW-1026)  
Pantech TXT8035PP  
Pantech TXT8040##  
Pantech WP8990  
PCD Razzle TXT8060  
Pharos PTL117  
Pharos PTL127  
RIM BlackBerry 8120  
RIM Blackberry 8220  
RIM Blackberry 8350i  
RIM Blackberry 8530  
Rim Blackberry 8820  
RIM Blackberry 9300  
RIM Blackberry 9500  
RIM Blackberry 9530  
RIM Blackberry 9630  
RIM Blackberry 9700  
Rim Blackberry Bold 9000  
RIM BlackBerry Curve (8520)  
Rim Blackberry Curve 8310  
Rim Blackberry Curve 8320  
Rim Blackberry Curve 8900  
Rim Blackberry Pearl 8100  
Rim Blackberry Pearl 8110  
RIM BlackBerry Storm 9550 (Storm 2)  
RIM Blackberry Curve 3G 9300  
RIM Blackberry Curve 3G 9330  
RIM Blackberry Storm 2  
RIM BlackBerry Style (9670)  
RIM BlackBerry Torch (9800)

RIM BlackBerryR 8530 Smartphone  
RIM BlackBerry 8910 Curve? Smartphone  
RIM BlackBerry Bold? 9000  
RIM BlackBerry Bold? 9650 Smartphone  
RIM BlackBerry Bold? 9650 Smartphone  
RIM BlackBerryR Bold? 9700  
RIM BlackBerryR Bold? 9780 smartphone  
RIM BlackBerryR Curve? 8330  
RIM BlackBerryR Curve? 8350i  
RIM BlackBerryR Curve? 8520 Smartphone  
RIM BlackBerryR Curve? 8900  
RIM BlackBerryR Curve? 9300  
RIM BlackBerryR Curve? 9330 Smartphone  
RIM BlackBerryR Pearl? 8230  
RIM BlackBerryR Pearl? 9100 Smartphone  
RIM BlackBerryR Pearl? 9105 Smartphone  
RIM BlackBerryR Storm2? 9520  
RIM BlackBerryR Storm2? 9550  
RIM BlackBerryR Storm? 9500  
RIM BlackBerryR Storm? 9530  
RIM BlackBerryR Style? 9670 Smartphone  
RIM BlackBerryR Torch? 9800  
RIM BlackBerryR Tour? 9630 Smartphone  
Samsung A237  
Samsung a727  
Samsung A737  
Samsung a747  
Samsung A767 Propel  
Samsung A777  
Samsung A827  
Samsung B2100  
Samsung B7300  
Samsung Behold 2 (T939)  
Samsung Behold T919  
Samsung BlackJack (TM ) II (i617)  
Samsung C3050  
Samsung C3110  
Samsung C5130  
Samsung C5212  
Samsung C5510  
Samsung D780  
Samsung D880  
Samsung D900i  
Samsung D988  
Samsung E390  
Samsung Eternity A867  
Samsung F110  
Samsung F330  
Samsung F480  
Samsung F490  
Samsung Flight  
Samsung Galaxy Spica GT-i5700  
Samsung Gravity 2 (T469)  
Samsung Gravity T459  
Samsung Highlight  
Samsung i200  
Samsung I450  
Samsung i520  
Samsung i640v

Samsung i7500 Galaxy  
Samsung i780  
Samsung i8000 Omnia  
Samsung i8510  
Samsung i8910 HD  
Samsung i907 Epix  
Samsung i910  
Samsung Impression (A877)  
Samsung Instinct HD (M850)  
Samsung Instinct S30  
Samsung Intensity  
Samsung Intrepid (I350)  
Samsung J200  
Samsung J700  
Samsung J758  
Samsung J808  
Samsung Jack i637  
Samsung L708  
Samsung L760  
Samsung L770  
Samsung M220  
Samsung M310  
Samsung M320  
Samsung M330  
Samsung M5650  
Samsung M630  
Samsung M7600  
Samsung M8910  
Samsung Magnet A257  
Samsung Moment  
Samsung Mythic A897  
Samsung Pixon M8800  
Samsung Propel (TM ) Pro i627  
Samsung Rant M540  
Samsung Reclaim (M560)  
Samsung Renown  
Samsung Rogue  
Samsung Rugby (A837)  
Samsung S3030 Tobi  
Samsung S3600H  
Samsung S3650 Corby  
Samsung S5230  
Samsung S5500  
Samsung S5550 Shark  
Samsung S5560  
Samsung S5600  
Samsung S5628 Monte  
Samsung S7070 Diva  
Samsung S7350  
Samsung S8000  
Samsung S8300  
Samsung Smooth  
Samsung Solstice (TM ) (A887)  
Samsung Steel U900  
Samsung t229  
Samsung t239  
Samsung t349  
Samsung T559 Comeback  
Samsung T659

Samsung t819  
Samsung T929 Memoir  
Samsung Trance  
Samsung u440  
Samsung U808  
Samsung A637  
Samsung A657  
Samsung Galaxy S i9000  
Samsung M520  
Samsung T339  
Samsung u430  
Samsung Wave S8500  
Samsung Alias 2 U750  
Samsung Captivate (I897)  
Samsung Continuum (I400)  
Samsung Epic 4G (D700)  
Samsung Fascinate (I500)  
Samsung C3050  
Samsung C3050  
Samsung C3110H  
Samsung C6625  
Samsung E3010  
Samsung GT- S8500  
Samsung GT-B2710  
Samsung GT-B2710D  
Samsung GT-B3210  
Samsung GT-B3310  
Samsung GT-B3310i  
Samsung GT-B3313i  
Samsung GT-B3410  
Samsung GT-B3410R  
Samsung GT-B3410W  
Samsung GT-B5210U  
Samsung GT-B5310  
Samsung GT-B5310B  
Samsung GT-B5310L  
Samsung GT-B5310R  
Samsung GT-B5310U  
Samsung GT-B6520  
Samsung GT-B6520L  
Samsung GT-B7300  
Samsung GT-B7300B  
Samsung GT-B7300C  
Samsung GT-B7320  
Samsung GT-B7320L  
Samsung GT-B7330  
Samsung GT-B7330B  
Samsung GT-B7330D  
Samsung GT-B7330R  
Samsung GT-B7350  
Samsung GT-B7350T  
Samsung GT-B7610  
Samsung GT-B7620  
Samsung GT-B7620U  
Samsung GT-C3010  
Samsung GT-C3013  
Samsung GT-C3050  
Samsung GT-C3050C  
Samsung GT-C3053

Samsung GT-C3060  
Samsung GT-C3200  
Samsung GT-C3300  
Samsung GT-C3300D  
Samsung GT-C3300i  
Samsung GT-C3300K  
Samsung GT-C3303K  
Samsung GT-C3500  
Samsung GT-C3503  
Samsung GT-C3510  
Samsung GT-C3510T  
Samsung GT-C3518  
Samsung GT-C3530  
Samsung GT-C5180  
Samsung GT-C5510  
Samsung GT-C5510H  
Samsung GT-C5510U  
Samsung GT-E2330B  
Samsung GT-E2530  
Samsung GT-E2652  
Samsung GT-E2652W  
Samsung GT-E3210  
Samsung GT-E3210B  
Samsung GT-E3210L  
Samsung GT-I5500  
Samsung GT-I5500M  
Samsung GT-I5503T  
Samsung GT-I5508  
Samsung GT-I5510  
Samsung GT-I5510B  
Samsung GT-I5510L  
Samsung GT-I5510T  
Samsung GT-I5700  
Samsung GT-I5700  
Samsung GT-I5700L  
Samsung GT-I5700U  
Samsung GT-I5800  
Samsung GT-I5801  
Samsung GT-I6220  
Samsung GT-I6230  
Samsung GT-I6410  
Samsung GT-I6500U  
Samsung GT-I6500U  
Samsung GT-I7410  
Samsung GT-I7500U  
Samsung GT-I7680  
Samsung GT-I8000H  
Samsung GT-I8000L  
Samsung GT-I8000T  
Samsung GT-I8180C  
Samsung GT-I8320  
Samsung GT-I8330  
Samsung GT-I8520  
Samsung GT-I8910L  
Samsung GT-I8910U  
Samsung GT-I9000  
Samsung GT-I9000  
Samsung GT-I9000B  
Samsung GT-I9000L

Samsung GT-I9000M  
Samsung GT-I9000M  
Samsung GT-I9000T  
Samsung GT-I9003  
Samsung GT-I9003  
Samsung GT-I9003L  
Samsung GT-I9003L  
Samsung GT-I9008  
Samsung GT-I9010  
Samsung GT-I9020  
Samsung GT-I9020A  
Samsung GT-I9020T  
Samsung GT-I9023  
Samsung GT-I9088  
Samsung GT-M2510C  
Samsung GT-M2513  
Samsung GT-M2520  
Samsung GT-M3710  
Samsung GT-M7500C  
Samsung GT-M7600B  
Samsung GT-M7600H  
Samsung GT-M7600L  
Samsung GT-M7603  
Samsung GT-M8910  
Samsung GT-M8910B  
Samsung GT-M8910U  
Samsung GT-P1000  
Samsung GT-P1000L  
Samsung GT-P1000N  
Samsung GT-P1000T  
Samsung GT-S3100  
Samsung GT-S3310i  
Samsung GT-S3350  
Samsung GT-S3353  
Samsung GT-S3370  
Samsung GT-S3370B  
Samsung GT-S3370C  
Samsung GT-S3370E  
Samsung GT-S3370L  
Samsung GT-S3500i  
Samsung GT-S3501C  
Samsung GT-S3550  
Samsung GT-S3600i  
Samsung GT-S3601C  
Samsung GT-S3650  
Samsung GT-S3650C  
Samsung GT-S3650W  
Samsung GT-S3653  
Samsung GT-S3653W  
Samsung GT-S5150  
Samsung GT-S5230  
Samsung GT-S5230C  
Samsung GT-S5230G  
Samsung GT-S5230N  
Samsung GT-S5233A  
Samsung GT-S5233S  
Samsung GT-S5233T  
Samsung GT-S5233W  
Samsung GT-S5250

Samsung GT-S5260  
Samsung GT-S5330  
Samsung GT-S5333  
Samsung GT-S5350  
Samsung GT-S5350L  
Samsung GT-S5510  
Samsung GT-S5510T  
Samsung GT-S5520  
Samsung GT-S5530  
Samsung GT-S5560  
Samsung GT-S5560C  
Samsung GT-S5560i  
Samsung GT-S5570  
Samsung GT-S5570B  
Samsung GT-S5570L  
Samsung GT-S5580  
Samsung GT-S5600  
Samsung GT-S5600B  
Samsung GT-S5600H  
Samsung GT-S5600L  
Samsung GT-S5600T  
Samsung GT-S5600V  
Samsung GT-S5603  
Samsung GT-S5603T  
Samsung GT-S5608U  
Samsung GT-S5620  
Samsung GT-S5620B  
Samsung GT-S5620L  
Samsung GT-S5628  
Samsung GT-S5628i  
Samsung GT-S5670  
Samsung GT-S5670B  
Samsung GT-S5670L  
Samsung GT-S5750E  
Samsung GT-S5830  
Samsung GT-S5830B  
Samsung GT-S5830L  
Samsung GT-S5830T  
Samsung GT-S6700T  
Samsung GT-S6703T  
Samsung GT-S6888  
Samsung GT-S7070  
Samsung GT-S7070C  
Samsung GT-S7220U  
Samsung GT-S7230  
Samsung GT-S7230B  
Samsung GT-S7230E  
Samsung GT-S7230L  
Samsung GT-S7233E  
Samsung GT-S7350i  
Samsung GT-S7350U  
Samsung GT-S7510  
Samsung GT-S8000B  
Samsung GT-S8000C  
Samsung GT-S8000C  
Samsung GT-S8000H  
Samsung GT-S8000L  
Samsung GT-S8000U  
Samsung GT-S8500

Samsung GT-S8500  
Samsung GT-S8500B  
Samsung GT-S8500C  
Samsung GT-S8500L  
Samsung GT-S8500M  
Samsung GT-S8500R  
Samsung GT-S8530  
Samsung GT-S8530B  
Samsung GT-S8530L  
Samsung Marcel\_Reloaded  
Samsung S3110C  
Samsung S3500C  
Samsung S7350B  
Samsung S7350C  
Samsung S7350L  
Samsung S8000  
Samsung S8300C  
Samsung S8300T  
Samsung S8300V  
Samsung Samsung GT-I5500B  
Samsung Samsung GT-I5500L  
Samsung Samsung GT-I5800L  
Samsung Samsung Mobile Phone (GT-M2510)  
Samsung Samsung Mobile Phone (SCH-R311)  
Samsung Samsung Mobile Phone (SCH-U350)  
Samsung Samsung Mobile Phone (SCH-U450)  
Samsung Samsung Mobile Phone (SCH-U960)  
Samsung Samsung Mobile Phone (SPH-M550)  
Samsung Samsung Mobile Phone (SPH-M560)  
Samsung Samsung Mobile Phone (SPH-M850)  
Samsung Samsung Mobile Phone(GT-I8000)  
Samsung Samsung Mobile Phone(I8910)  
Samsung Samsung Mobile Phone(M7600)  
Samsung Samsung Mobile Phone(SCH-R560)  
Samsung Samsung Mobile Phone(SCH-U430)  
Samsung Samsung Mobile Phone(SCH-U640)  
Samsung SC-01B  
Samsung SC-01C  
Samsung SC-02B  
Samsung SCH-F809  
Samsung SCH-F859  
Samsung SCH-I100  
Samsung SCH-i220  
Samsung SCH-i220(MPCS)  
Samsung SCH-i225  
Samsung SCH-i329  
Samsung SCH-I400  
Samsung SCH-I500  
Samsung SCH-I520  
Samsung SCH-I579  
Samsung SCH-I800  
Samsung SCH-i899  
Samsung SCH-I909  
Samsung SCH-i920  
Samsung SCH-M710  
Samsung SCH-M715  
Samsung SCH-M720  
Samsung SCH-R100  
Samsung SCH-R250

Samsung SCH-R260  
Samsung SCH-R260  
Samsung SCH-R260  
Samsung SCH-R260  
Samsung SCH-R312  
Samsung SCH-R330  
Samsung SCH-R330  
Samsung SCH-R335  
Samsung SCH-R350  
Samsung SCH-R351  
Samsung SCH-R360  
Samsung SCH-R520  
Samsung SCH-R570  
Samsung SCH-R580  
Samsung SCH-R630  
Samsung SCH-R631  
Samsung SCH-R631 2Thumb  
Samsung SCH-R700  
Samsung SCH-R710  
Samsung SCH-R850  
Samsung SCH-R860  
Samsung SCH-R880  
Samsung SCH-R880  
Samsung SCH-R900  
Samsung SCH-R910  
Samsung SCH-R915  
Samsung SCH-U350  
Samsung SCH-U360  
Samsung SCH-U370  
Samsung SCH-U450  
Samsung SCH-U450  
Samsung SCH-U450(Verizon)  
Samsung SCH-U460  
Samsung SCH-U820  
Samsung SCH-W899  
Samsung SGH-C414  
Samsung SGH-C414Y  
Samsung SGH-I896  
Samsung SGH-I897  
Samsung SGH-I897  
Samsung SGH-i917  
Samsung SGH-I917R  
Samsung SGH-I997  
Samsung SGH-J600E  
Samsung SGH-T259  
Samsung SGH-T499  
Samsung SGH-T759  
Samsung SGH-T839  
Samsung SGH-T939  
Samsung SGH-T959  
Samsung SGH-T959  
Samsung SGH-T959D  
Samsung SGH-T959D  
Samsung SGH-T959D  
Samsung SGH-T959V  
Samsung SHC-Z120L  
Samsung SHW-A280K  
Samsung SHW-A280L  
Samsung SHW-A280S

Samsung SHW-M100S  
Samsung SHW-M110S  
Samsung SHW-M110S  
Samsung SHW-M110S  
Samsung SHW-M120S  
Samsung SHW-M130K  
Samsung SHW-M130K  
Samsung SHW-M130L  
Samsung SHW-M130L  
Samsung SHW-M135K  
Samsung SHW-M135L  
Samsung SHW-M180K  
Samsung SHW-M180L  
Samsung SHW-M180S  
Samsung SHW-M180W  
Samsung SHW-M185S  
Samsung SHW-M190S  
Samsung SHW-M200K  
Samsung SHW-M200S  
Samsung SHW-M210S  
Samsung SPH-D700  
Samsung SPH-i350  
Samsung SPH-M260  
Samsung SPH-M330  
Samsung SPH-M340  
Samsung SPH-M350  
Samsung SPH-M360  
Samsung SPH-M380  
Samsung SPH-M560  
Samsung SPH-M570  
Samsung SPH-M575  
Samsung SPH-M7200  
Samsung SPH-M7350  
Samsung SPH-M8400  
Samsung SPH-M900  
Samsung SPH-M900  
Samsung SPH-M910  
Samsung SPH-P100  
Samsung SWD-S500  
Samsung X01SC  
Sanyo Incognito (SCP-6760)  
Sanyo Katana Eclipse  
Sanyo Katana LX  
Sanyo PRO-700  
Sanyo SCP-2700  
Sanyo SCP-3810  
Sonim Sonim XP1300-A-R1 (Type: P25B005AA)  
Sonim Sonim XP1300-E-R1 (Type: P24B005AA)  
Sonim Sonim XP3300-A-R1 (Type: P25C005AA)  
Sonim Sonim XP3300-E-R1 (Type: P24C005AA)  
Sony Equinox  
Sony Ericsson C510 Black  
Sony Ericsson C901  
Sony Ericsson C902  
Sony Ericsson C905 Black  
Sony Ericsson F305  
Sony Ericsson G502  
Sony Ericsson G700  
Sony Ericsson G705

Sony Ericsson G900  
Sony Ericsson J105i  
Sony Ericsson S302  
Sony Ericsson T650i  
Sony Ericsson T700  
Sony Ericsson T715  
Sony Ericsson TM506  
Sony Ericsson W300i  
Sony Ericsson W302  
Sony Ericsson W350 (Refurbished)  
Sony Ericsson W350a  
Sony Ericsson W518a  
Sony Ericsson W580i  
Sony Ericsson W595  
Sony Ericsson W660i  
Sony Ericsson W705  
Sony Ericsson W760a  
Sony Ericsson W810i  
Sony Ericsson W850i  
Sony Ericsson W960i  
Sony Ericsson W980  
Sony Ericsson Xperia X1  
Sony Ericsson Z310a  
Sony Ericsson Z750a  
Sony Ericsson Z770i  
Sony Ericsson Aino  
Sony Ericsson Aino/ U10  
Sony Ericsson ASPEN  
Sony Ericsson C510, C510a  
Sony Ericsson C901, C901a  
Sony Ericsson C903, C903a  
Sony Ericsson Cedar?  
Sony Ericsson Elm  
Sony Ericsson F100i  
Sony Ericsson Hazel  
Sony Ericsson J105 (Naite?)  
Sony Ericsson Satio/ U1  
Sony Ericsson Sony Ericsson A8i  
Sony Ericsson T707, T707a  
Sony Ericsson T715  
Sony Ericsson TM717  
Sony Ericsson U10  
Sony Ericsson Vivaz?  
Sony Ericsson Vivaz? pro  
Sony Ericsson W508, W508a  
Sony Ericsson W518a  
Sony Ericsson W705, W705u, W705a  
Sony Ericsson W715  
Sony Ericsson W995, W995a  
Sony Ericsson Xperia Pureness/ X5  
Sony Ericsson Xperia X10  
Sony Ericsson Xperia? X10 mini (Rev 2)  
Sony Ericsson Xperia? X10 mini pro (Rev2)  
Sony Ericsson Xperia? X8  
Sony Ericsson Yari  
Sony Ericsson Zylo?  
SonyEricsson Aion U10  
SonyEricsson C903  
SonyEricsson Elm J10

SonyEricsson F100  
SonyEricsson Hazel J20  
SonyEricsson K510a  
SonyEricsson K660i  
SonyEricsson Satio U1i  
SonyEricsson Vivaz U5  
SonyEricsson W395  
SonyEricsson W902  
SonyEricsson W995  
SonyEricsson X10  
SonyEricsson X10 mini  
SonyEricsson X10 mini pro  
SonyEricsson X2  
SonyEricsson Yari U100  
SonyEricsson Z550a  
SonyEricsson Z555  
T-Mobile T-Mobile Wing (S730)  
T-Mobile G2  
T-Mobile MyTouch 3G Slide  
T-Mobile MyTouch 4G  
UT Starcom CDM8950  
UT Starcom GZ1 C711  
VN610/ AN610  
ZTE 003Z  
ZTE a5  
ZTE Android Edition Starnaute  
ZTE BJK1903  
ZTE F160  
ZTE F870  
ZTE F870E  
ZTE F930  
ZTE F950  
ZTE F951  
ZTE F951E  
ZTE Jack 3G  
ZTE San Francisco  
ZTE T870  
ZTE T930  
ZTE Tactile internet 2  
ZTE Venus  
ZTE Vodafone 945  
ZTE XCD35  
ZTE ZTE F870  
ZTE ZTE F951  
ZTE ZTE F952 UM KP  
ZTE ZTE-1001  
ZTE ZTE-BLADE  
ZTE ZTE-C F350  
ZTE ZTE-U X990  
ZTE ZTE-U X991